

Do's for Solar Inverter Care

- Install the inverter in a well-ventilated, shaded, and dry location.
- Ensure proper grounding and earthing for safety.
- Regularly clean the inverter's surface and surrounding area to avoid dust buildup.
- Monitor inverter performance using the display or mobile app.
- Schedule periodic servicing as recommended by the manufacturer.
- Switch off the inverter safely before performing any maintenance.
- Keep cables, connectors, and fuses checked for tightness and wear.
- Use only authorized accessories and spare parts.

Don'ts for Solar Inverter Care

- Don't expose the inverter to direct sunlight, rain, or extreme temperatures.
- Don't place heavy objects or liquids on or near the inverter.
- Don't block air vents or cooling fans.
- Don't open or tamper with the inverter yourself – always call a qualified technician.
- Don't ignore error messages or unusual noises.
- Don't connect unauthorized batteries or incompatible panels.
- Don't overload the inverter beyond its rated capacity.
- Don't delay servicing when the system shows warning signs.